

User Manual

VR30

Date: May 2025

Doc Version: 1.0

English

Thank you for choosing our product. Please read the instructions carefully before operation. Follow these instructions to ensure that the product is functioning properly. The images shown in this manual are for illustrative purposes only.



For further details, please visit our Company's website
www.zkteco.com.

Copyright © 2025 ZKTECO CO., LTD. All rights reserved.

Without the prior written consent of ZKTeco, no portion of this manual can be copied or forwarded in any way or form. All parts of this manual belong to ZKTeco and its subsidiaries (hereinafter the "Company" or "ZKTeco").

Trademark

ZKTeco is a registered trademark of ZKTeco. Other trademarks involved in this manual are owned by their respective owners.

Disclaimer

This manual contains information on the operation and maintenance of the ZKTeco equipment. The copyright in all the documents, drawings, etc. in relation to the ZKTeco supplied equipment vests in and is the property of ZKTeco. The contents hereof should not be used or shared by the receiver with any third party without express written permission of ZKTeco.

The contents of this manual must be read as a whole before starting the operation and maintenance of the supplied equipment. If any of the content(s) of the manual seems unclear or incomplete, please contact ZKTeco before starting the operation and maintenance of the said equipment.

It is an essential pre-requisite for the satisfactory operation and maintenance that the operating and maintenance personnel are fully familiar with the design and that the said personnel have received thorough training in operating and maintaining the machine/unit/equipment. It is further essential for the safe operation of the machine/unit/equipment that personnel has read, understood and followed the safety instructions contained in the manual.

In case of any conflict between terms and conditions of this manual and the contract specifications, drawings, instruction sheets or any other contract-related documents, the contract conditions/documents shall prevail. The contract specific conditions/documents shall apply in priority.

ZKTeco offers no warranty, guarantee or representation regarding the completeness of any information contained in this manual or any of the amendments made thereto. ZKTeco does not extend the warranty of any kind, including, without limitation, any warranty of design, merchantability or fitness for a particular purpose.

ZKTeco does not assume responsibility for any errors or omissions in the information or documents which are referenced by or linked to this manual. The entire risk as to the results and performance obtained from using the information is assumed by the user.

ZKTeco in no event shall be liable to the user or any third party for any incidental, consequential, indirect, special, or exemplary damages, including, without limitation, loss of business, loss of profits, business interruption, loss of business information or any pecuniary loss, arising out of, in connection with, or

relating to the use of the information contained in or referenced by this manual, even if ZKTeco has been advised of the possibility of such damages.

This manual and the information contained therein may include technical, other inaccuracies or typographical errors. ZKTeco periodically changes the information herein which will be incorporated into new additions/amendments to the manual. ZKTeco reserves the right to add, delete, amend or modify the information contained in the manual from time to time in the form of circulars, letters, notes, etc. for better operation and safety of the machine/unit/equipment. The said additions or amendments are meant for improvement /better operations of the machine/unit/equipment and such amendments shall not give any right to claim any compensation or damages under any circumstances.

ZKTeco shall in no way be responsible (i) in case the machine/unit/equipment malfunctions due to any non-compliance of the instructions contained in this manual (ii) in case of operation of the machine/unit/equipment beyond the rate limits (iii) in case of operation of the machine and equipment in conditions different from the prescribed conditions of the manual.

The product will be updated from time to time without prior notice. The latest operation procedures and relevant documents are available on <http://www.zkteco.com>.

If there is any issue related to the product, please contact us.

ZKTeco Headquarters

Address ZKTeco Industrial Park, No. 32, Industrial Road,
Tangxia Town, Dongguan, China.

Phone +86 769 - 82109991

Fax +86 755 - 89602394

For business related queries, please write to us at: sales@zkteco.com.

To know more about our global branches, visit www.zkteco.com.

About the Company

ZKTeco is one of the world's largest manufacturer of RFID and Biometric (Fingerprint, Facial, Finger-vein) readers. Product offerings include Access Control readers and panels, Near & Far-range Facial Recognition Cameras, Elevator/Floor access controllers, Turnstiles, License Plate Recognition (LPR) gate controllers and Consumer products including battery-operated fingerprint and face-reader door locks. Our security solutions are multi-lingual and localized in over 18 different languages. At the ZKTeco state-of-the-art 700,000 square foot ISO9001-certified manufacturing facility, we control manufacturing, product design, component assembly, and logistics/shipping, all under one roof.

The founders of ZKTeco have been determined for independent research and development of biometric verification procedures and the productization of biometric verification SDK, which was initially widely applied in PC security and identity authentication fields. With the continuous enhancement of the development and plenty of market applications, the team has gradually constructed an identity authentication ecosystem and smart security ecosystem, which are based on biometric verification techniques. With years of experience in the industrialization of biometric verifications, ZKTeco was officially established in 2007 and now has been one of the globally leading enterprises in the biometric verification industry owning various patents and being selected as the National High-tech Enterprise for 6 consecutive years. Its products are protected by intellectual property rights.

About the Manual

This manual introduces the operations of **VR30**.

All figures displayed are for illustration purposes only. Figures in this manual may not be exactly consistent with the actual products.

Document Conventions

Conventions used in this manual are listed below:

GUI Conventions

For Software	
Convention	Description
Bold font	Used to identify software interface names e.g. OK , Confirm , Cancel .
>	Multi-level menus are separated by these brackets. For example, File > Create > Folder.
For Device	
Convention	Description
< >	Button or key names for devices. For example, press <OK>.
[]	Window names, menu items, data table, and field names are inside square brackets. For example, pop up the [New User] window.
/	Multi-level menus are separated by forwarding slashes. For example, [File/Create/Folder].

Symbols






Convention	Description
	This represents a note that needs to pay more attention to.
	The general information which helps in performing the operations faster.
	The information which is significant.
	Care taken to avoid danger or mistakes.
	The statement or event that warns of something or that serves as a cautionary example.

Table of Contents

1 PRODUCT INTRODUCTION.....	6
2 FUNCTIONS.....	6
3 APPEARANCE AND DIMENSIONS.....	7
4 PARAMETERS.....	7
5 INSTALLATION INSTRUCTION.....	9
6 PRODUCT INSTALLATION.....	10
7 WIRING.....	11
8 DEBUG RADAR WITH APP (ZKEASY GO).....	14
8.1 DOWNLOAD AND INSTALL THE APP TO THE PHONE.....	14
8.2 CONNECT TO BLUETOOTH.....	15
8.3 SET PARAMETER FOR RADAR.....	17
8.3.1 PARAMETER DESCRIPTION.....	18
8.4 DISPLAY OF TARGET INFORMATION.....	19
9 FAQ.....	20
10 PACKING LIST.....	20

1 Product Introduction


VR30 is the third generation of ZKTeco radars developed to detect and identify various vehicles (motorcycle, cars, trucks, etc.) and pedestrians near the barrier gate. It adopts highly integrated radio frequency chip, which has the characteristics of small size, low cost, all-weather work all day, high detection sensitivity, high accuracy, simple commissioning and installation, stability and reliability.

The VR30 is a 79GHz millimeter-wave barrier anti smashing radar with high measurement accuracy. Through the joint optimization design of software and hardware, this product can accurately identify and distinguish between pedestrians and vehicles passing through the barrier area, and prevent the barrier from hitting people and cars. Also, users could set parameters of VR30 with a mobile app (ZKEasy Go) when connected it to Bluetooth.

2 Functions

- High detection accuracy
- Simple installation and debugging, saving labor and material cost.
- The radar work is not affected by the external environment such as light, dust, rain and snow.
- Supports Bluetooth communication, allowing upgrade and debug with a mobile App (ZKEasy Go).
- Straight boom are supported by default. Also support folding boom, fence boom, and advertising boom (need to learn to record the environment).

3 Appearance and Dimensions



4 Parameters

Model	VR30
Detection Distance	1m to 7m
Working Voltage (V)	DC 12V
Power Consumption (W)	≤1.3
Working Temperature (℃)	-40℃ to 85℃
Antenna Transmit Power	10dBm
Antenna Gain	14dBi
Communication Interface	Bluetooth, relay
Azimuth Field of View	-60° to 60°
Vertical Field of View	-10° to 10°

Shell Size (L*H*W)	101*78*19mm
Protection Level	IP67
Supported App	ZKEasy Go

5 Installation Instruction

1. According to the actual situation on site, select the corresponding parameters of radar.
2. Cannot be applied to other sliding doors and telescopic doors.




3. After changing the detection environment (such as installing a deflector, ice cream cone in the detection area), please re-learn to record the environment again by App.
4. Under normal circumstances, please set the detection distance according to the length of the boom. The detection distance is slightly less than or equal to the length of the boom to prevent people or objects outside the barrier boom from being detected by the radar.
5. If there is a misrecognition due to radar causing opening the gate or not closing, please re-learn the background.
6. The radar antenna is integrated inside. When the radar surface is covered with foreign objects (such as water drops, rain, snow, dust, etc.), it should be cleaned in time.
7. The detection field of the radar must be clean, and there must be no objects that affect the target detection (such as metal fences, billboards, license plate recognition cameras, walls, etc.) to prevent the radar from being triggered by mistake.
8. It is not recommended to use the radar in the fence and advertisement boom type for a single mixed-in and mixed-out scenario.
9. Dual-radar installation is recommended for semi-trailer, cement tanker, crane.
10. When learning to record the environment, the fence/advertisement boom may shaking after the it falls to the ground, and then wait for the boom to fully stabilize before performing subsequent operations.

6 Product Installation

1. Confirm radar mounting holes

The installation hole of the radar is between 100 to 200mm from the inside of the straight boom and between 200 to 300mm from the inside of the non-straight boom. The installation height of radar is 650 to 700mm from the driveway ground for small car; Two radars are recommended for large car, with installation height of 650 to 700mm and 1000 to 1100mm. The installation position is shown in the figure.



2. Drilling

Use an electric drill to drill holes in the selected position, the size of holes are $\Phi 8\text{mm}$. After drilling the crossing holes and fixing holes, put the radar cable through the crossing hole and tighten the fixing holes with screw to ensure that the radar does not wobble.

7 Wiring

1. Interface cable description


Cable Identification	Cable Color	Description	Wiring
12V	Red	Power	The red wire connected to the 12V power positive output terminal;
GND	Black	GND	The black wire "GND" is connected to the negative output terminal of the 12V power supply.
Normally Open Signal Wire	Blue	COM	The blue and orange wires are normally open signals of the relay, connecting the ground sense coil terminals and the common terminals of the barrier control main board (no distinction between positive and negative).
	Orange	NO1	
TX	White	485-B/TTL	Connected to T/R+ terminal of 485.(Default TTL)
RX	Purple	485-A/TTL	
Button	Green	Configuration button	Reserve
	Yellow		




Note: Every time before debugging wiring or unplugging wires, must be disconnected from the power supply, at the same time, pay attention to the white and purple wires can not touch the positive pole of the 12V power supply.

2. Connected to the barrier gate


When the radar is connected to the PB4000, CMP200, BGM series barrier gate, the normally open signal wire of the radar, that is, the blue and orange wires, are connected to the ground sense coil terminals and common terminals of the barrier control main board (no distinction between positive and negative).



Radar connected to PB4000 barrier gate




Radar connected to CMP200 barrier gate



Radar connected to BGM series barrier gate

Note: ProBG (Wiring)

When the radar is connected to the ProBG series barrier gate, the normally close signal wires of the radar, that is, the brown and purple wires, are connected to the ground sense coil terminals and common terminals of the barrier control main board (no distinction between positive and negative).



Radar connected to ProBG series barrier gate

8 Debug Radar with App (ZKEasy Go)

8.1 Download and Install the App to the Phone

1. If the system of phone is android, go to the Google Play and search "ZKEasy Go" for downloading it.



QR code for android phone(Android 10+)

2. If the system of phone is iOS, go to the App Store and search "ZKEasy Go" for downloading it.




QR code for IOS(IOS 12.0+)

8.2 Connect to Bluetooth


1. Turn on the device's Bluetooth

Bluetooth is automatically turned on by default when the radar device is powered on.


2. Open ZKEasy Go app, select the **[Parking]** interface and click **[Barrier Radar]** icon to connect the device.



3. Open the Bluetooth and location of the phone, and click **[Device connect]** to connect the radar.




4. Choose the corresponding Bluetooth to connect it. Once the Bluetooth connected, It will automatically go to the Bluetooth settings screen.



8.3 Set Parameter for Radar

Enter the parameter setting interface as the pictures shown below.



Step 1: According to the actual installation environment, choose the **Vehicle Type**, **Boom Type** and **Boom length**. On the setting of **Boom length** is generally recommended to set the length shorter than the actual length of 50cm.

Step 2: Setting the **Fixed mode**: back to the radar, the barrier boom on the left side of the radar is **left fixed**, barrier boom on the right side of the radar is **right fixed**.

Step 3: Slide to the bottom of this screen and click [**Save Radar Parameters**].

Step 4: First keep the barrier boom in a raise state and make sure no one enters within 150cm to the left and right of the radar, then click [**Background Learning**] in the app. Follow the prompts until the learning is complete.


Step 5: Make sure no one enters within 150cm to the left and right of the radar, then click [**Boom Up and Down Learning**] in the app. Follow the prompts, using the remote control to keep opening and closing the barrier boom until the learning is complete.

Step 6: After finish **step 5**, the barrier boom will close, the radar indicator green light off, the radar into the self-learning, at this time to make sure no one enters within 150cm to the left and right of the radar in 30s. After 30s, the radar self-learning is completed and the setting of radar is finished.

Note:

1. In general scenarios, just follow the above steps to configure, no need to do other configurations.
2. If you have modified the **Boom Type**, **Boom length** or **Fixed mode**, please reset from step 3, otherwise will have problems such as smashing the car.

8.3.1 Parameter Description



Pedestrian-vehicle Distinction: This mode means that the radar will distinguish between pedestrian and vehicle. If turn it on, the indicator light will be yellow when detect a person.

Direction of vehicle moving: Entering from the left ,right side or both side of the radar.

Relay Status: Normally open and normally closed options.

Delayed boom closing time: Delayed closing of the barrier boom after the vehicle leaves.

Proximal non-detection distance: The distance in front of the radar that will not be detected by radar, for example, if the value is set as 0.4m, object 0.4m from radar will not be detected.


Left detection area scope: The left scope of the radar detection area.

Right detection area scope: The right scope of the radar detection area.

Cutting Area: If the site environment has a small obstacle in the detection area can occasionally be detected, in this situation you can draw a area according to the coordinate value that check from the **Target Chart**, all the point in this area are eliminated which means that the radar will not detect this area. For example, the obstacle of XY coordinates for (0.4,3), then you can draw a area such as $X1 = 0.2$, $X2 = 0.6$, $Y1 = 2.8$, $Y2 = 3.2$ cut area.

8.4 Display of Target Information

1. After the background learning is completed, you can click to display the target information. During this process, please do not perform other operations except stop the display.



2. If there is false alarm on the interface, click **[STOP DISPLAY]** and then click **[ELIMINATE FALSE ALARM]**. After Eliminate false alarm, it can be used normally.

9 FAQ

- **Problem:** After installation, the green light of the radar is always on, and the boom does not fall.

Possible cause: The Newly added strong reflector in the radar detection range needs to be moved out of the radar field of view or re-learned for background learning.

- **Problem:** The person is standing in front of the radar and the green light is not on.

Possible cause: The radar starts to detect the difference between people and vehicles after the car triggers the radar light.

- **Problem:** The red light of radar flashes when the 12V power supplied by the gate control board is on.

Possible cause: It is recommended to connect an external 12V-1A power adapter.

10 Packing List

Number	Accessories	Quantity
1	VR30 Radar	1
2	Fixed nut	1
3	Installation aid stickers	1

ZKTeco Industrial Park, No. 32, Industrial Road,

Tangxia Town, Dongguan, China.

Phone : +86 769 - 82109991

Fax : +86 755 - 89602394

www.zkteco.com



Copyright © 2021 ZKTECO CO., LTD. All Rights Reserved.