

Quick Start Guide

EFace10

Version: 1.1

Due to regular upgrades of systems and products, ZKTeco could not guarantee exact consistency between the actual product and the written information in this manual.

Overview



Note: Features and parameters with ★ mark are not available in all devices.

Installation Environment

Please refer to the following recommendations for installation.



INSTALL INDOORS ONLY



AVOID INSTALLATION NEAR GLASS WINDOWS



AVOID DIRECT SUNLIGHT AND EXPOSURE



AVOID USE OF ANY HEAT SOURCE NEAR THE DEVICE

Recommended Standing Position



KEEP EFFECTIVE DISTANCE OF 0.3-2m

Standalone Installation



Power Connection



Recommended AC Adapter

- 1) 12V ± 10%, at least 1500mA.
- 2) To share the power with other devices, use an AC Adapter with higher current ratings.

Ethernet Connection

Connect the device and computer software over an Ethernet cable. As shown in the example below:



Click on [COMM.] > [Ethernet] > [IP Address], input the IP address and click on [OK].

Note: In LAN, the IP addresses of the server (PC) and the device must be in the same network segment when connecting to the **ZKBioAccess IVS** software.

Lock Relay Connection

The system supports **Normally Opened Lock** and **Normally Closed Lock**. The **NO Lock** (normally opened when powered) is connected with '**NO**' and '**COM**' terminals, and the **NC Lock** (normally closed when powered) is connected with '**NC**' and '**COM**' terminals. An example with NC lock is shown below:

Device not sharing power with the lock



Door Sensor, Exit Button & Auxiliary Input Connection



Note: Backup rechargeable battery: Offers at least 2 hours of power on a full charge, and it takes 4 hours to recharge.

User Registration

When there is no super administrator set in the device, click on \equiv to enter the menu. Add a new user and set User Role to Super Admin, then the system requests for the administrator's verification before entering the menu. It is recommended to register a super administrator initially for security purposes.

Method 1: Registering on the device

Click on \equiv > [User Mgt.] > [New User] to register a new user. The options include entering the user ID and Name, setting User Role and Verification Mode, registering Face, Card Number \bigstar , Password, and adding User Photo.





Ð	User Mgt.	
Prew User		
🗾 All Users 💟		
😥 Display Style		

Ð	New User	11
User ID		3
Name		
User Role		Normal User
Verification Mode		Password/Card/Face
Face		0
Card Number		





Method 2: Register on ZKBioAccess IVS software

Please set the IP address and cloud service server address in the Comm. Menu option on the device.

1. Click [Attendance] > [Attendance Device] > [Device] > [Search] to search the device on the software. When an appropriate server address and port is set on the device, the searched devices are displayed automatically.



- 2. Click [Add] in operation column, a new window will pop-up. Select Attendance Area and Time zone from each dropdowns and click [OK] to add the device.
- Click [Personnel] > [Person] > [New] and fill in all the required fields to register a new users in the software.
- Click [Attendance Device] > [Device] > [Control] > [Synchronize Software Data to the Device] tosynchronize all the data to the device including the new users.

For more details, please refer to the ZKBioAccess IVS User Manual.

Method 3: Register on the phone

Once the ZKBioAccess IVS software is installed, the users could enroll their face via a browser application on their own mobile phone.

 Click [Personnel] > [Parameters], input "http://Server address: Port" in the QR Code UGL bar. The software will automatically generate a QR code. Scan the QR code or login onto "http://Server address: Port/app/v1/adreg" by the mobile phone to register users.



 The users will be displayed in [Personnel] > [Pending Review], click on [Review] option and assign a department and click [OK] to successfully add the user.



Ethernet and Cloud Server Settings

Click on \equiv > [COMM.] > [Ethernet] to set the network parameters. If the TCP/IP communication of the device is successful, the icon \square will be displayed in the upper right corner of the standby interface.

Click on \equiv > [COMM.] > [Cloud Server Setting] to set the server address and server port, that is, the IP address and port number of the server after the software is installed. If the device communicates with the server successfully, the icon \cong will be displayed in the upper right corner of the standby interface.



Ð	Ethernet	11	Ð	Cloud Server Setting	
IP Address		192.168.163.99	Server Mode		
Subnet Mask		255.255.255.0	Enable Domain Name		
Gateway		192.168.163.1	Server Address		
DNS		0.0.0.0	Server Port		
TCP COMM.Part		4370	Enable Proxy Server		
DHCP		0	HTTPS		

Note:

While pairing the device with ZKBioAccess IVS software. Make sure that the option **Enable Domain Name** is disabled and the correct server address and port are entered. **Server Address:** Set as the IP address of the ZKBioAccess IVS server.

Server Port: Set as the service port of ZKBioAccess IVS.

Access Control Setting

Click on \equiv > [Access Control] to enter the access control management interface and set relevant parameters of access control.



10
Normal Close (NC)

Attendance Record

Click on $(\equiv) > [Attendance] > [Attendance Record]$ to enter the record query interface, input the user ID and select the time range, the corresponding attendance record will be displayed.



Ð	Attendance Search
E Attend	ance Record
I Attend	ance Photo
Blocklin	st ATT Photo

5	User ID		
Please Input(query all data without input)			
-			
1	2	3	\times
4	5	6	^
7	8	9	\sim
ESC	0	123	ок

Personal Record Search	
User ID	Time
	Number of Records:04
2	09:58 09:53 09:51 09:48
	Number of Records:09
1	16:17 16:01 15:57
2	16:17 16:09 16:02 16:01 15:58
	15:57
	User ID 2 1

ZKTeco Industrial Park, No. 32, Industrial Road,

Tangxia Town, Dongguan, China.

Phone :+86 769 - 82109991

Fax :+86755-89602394

www.zkteco.com



Copyright © 2022 ZKTECO CO., LTD. All Rights Reserved.